


Kraftstichsäge - Carbody Saw - Carrosseriezaag



ITEM NO.	REF. NO.	DESCRIPTION
1	BJ0001	VALVE SCREW
2	BJ0002	O-RING
3	BJ0003	O-RING
4	BJ0004	AIR CONTROLLER
5	BJ0005	VALVE SPRING
6	BJ0006	VALVE STEM
7a	BJ0007	O-RING
7b	BJ0008	O-RING
8	BJ0009	VALVE BUSHING
9	BJ0010	INLET BUSHING
10	BJ0011	CAP SCREW (4)
11	BJ0012	WESHER (4)
12	BJ0013	LEVER PIN
13	BJ0014	THROTTLE LEVER
15	BJ0015	VALVE CASE
16	BJ0016	BUSH
17	BJ0017	CYLINDER
18	BJ0018	VALVE STEEVE
19	BJ0019	ACTUATE VALVE
20	BJ0020	WASHER
21	BJ0021	CAP SCREW (3)
22	BJ0022	GASKET
23	BJ0023	VALVE BLOCK
24	BJ0024	SET SCREW (2)
25	BJ0025	BUSH (2)
26	BJ0026	CHUCK COVER
27	BJ0027	SCREW (2)

ITEM NO.	REF. NO.	DESCRIPTION
28	BJ0028	HOUSING
28a	BJ0029	PLASTIC WRAPP
29	BJ0030	PISION ASS'Y
30	BJ0031	SET SCREW (2)
31	BJ0032	SERVICE WRENCH (2mm)
32	BJ0033	GUIDE PLETE
33	BJ0034	BIEDE CHUCK
34a	BJ0035	WORK GUIDE (LONG)
34b	BJ0036	WORK GUIDE (SHORT)
35a	BJ0037	BLADE (32T)
35b	BJ0038	BLADE (24T)
35c	BJ0039	BLADE (18T)
35d	BJ0040	BLADE (14T)
36	BJ0041	SERVICE WRENCH (4mm)
38	BJ0042	SCREW (2)
38a	BJ0043	RETAINING RING
39	BJ0044	UPER WEAR SHOE
40	BJ0045	BIADE GUIDE (2)
41	BJ0046	BRIDGE
42	BJ0047	FORNT BUMPER
43	BJ0048	REAR BUMPER
44	BJ0049	RELL PIN (2)
45	BJ0050	SPRING
46	BJ0051	PACKING
47	BJ0052	PACKING
48	BJ0053	PACKING
49	BJ0054	SET SCREW