


Screwdriver - Drehschrauber - Schroevendraaier - Viseuse



ITEM NO.	REF. NO.	DESCRIPTION
1	BJ0001	HOUSING
2	BJ0002	PIN
3	BJ0003	AIR INLET
4	BJ0004	TRIGGER
5	BJ0005	VALVE STEM
6	BJ0006	REVERSE BUSHING
7	BJ0007	O-RING
7A	BJ0008	O-RING
8	BJ0009	VALVE SPRING
9	BJ0010	O-RING
10	BJ0011	REVERSE LEVER
13	BJ0012	BALL BEARING (2)
14	BJ0013	END PLATE (2)
15	BJ0014	ROTOR
16	BJ0015	ROTOR BLADE (5)
17	BJ0016	PIN
18	BJ0017	CYLINDER
19	BJ0018	SPACER
20	BJ0019	SPRING
21	BJ0020	SPRING GUIDE
22	BJ0021	INTERNAL GEAR (2)
23	BJ0022	PLANET GEAR (6)
24	BJ0023	PIN (6)
26	BJ0024	WORK SPINDLE
27	BJ0025	BALL BEARING

ITEM NO.	REF. NO.	DESCRIPTION
28	BJ0026	CLAMP NUT
29	BJ0027	DRIVE DOG
30	BJ0028	RETAINING RING (3)
31	BJ0029	RETAINING RING
32	BJ0030	CAM SPINDLE
33	BJ0031	STEEL BALL
34	BJ0032	CLUTCH CARRIER
35	BJ0033	STEEL BALL (4)
36	BJ0034	WASHER
37	BJ0035	SPRING
38	BJ0036	WASHER
39	BJ0037	ADJUST NUT
40	BJ0038	SPACER
41	BJ0039	CLUTCH HOUSING
42	BJ0040	BALL RETAINER
43	BJ0041	SPRING
44	BJ0042	WASHER
45	BJ0043	PINION GEAR
46	BJ0044	SET SCREW
47	BJ0045	O-RING
48	BJ0046	EXHAUST DIFFUSER
49	BJ0047	SCREW (2)
50	BJ0048	REDUCTION SPINDLE
51	BJ0049	CENTER GEAR